


50X1-HUM

**Page Denied**

50X1-HUM


SECRET



**DISTILLING SYSTEM**  
**Description and Maintenance**  
**Instructions**

H641-A76-206

SECRET



50X1-HUM

SECRET

50X1-HUM

I. DESCRIPTIONA. PURPOSE AND BASIC SPECIFICATIONS

The system is intended to receive, store and feed the distillate to the battery wells for battery make-up. As distilled water is consumed, replenishing the stowage tanks is accomplished by the use of the electric distilling plant.

The distilled water stowage tanks are of the following stowage capacities:

tank No.1 - 2730 lit;  
tank No.2 - 2060 lit.

The total distilled water stowage capacity of the submarine is 4790 lit.

The basic characteristics of the distilling system pipe lines are tabulated below.

Table 1

No.	Pipe line	External dia. and thickness of pipe wall	Material		Remarks
			pipes	fittings	
1	Distilled water	32 x 2 25 x 1.5 14 x 1.5	stainless steel	stainless steel, brass	
2	Air pipe line	14 x 1.5 6 x 1.5	stainless steel	stainless steel, brass	

Test pressures of the pipe lines are given in Table 2.

SECRET

50X1-HUM

SECRET

50X1-HUM

Table 2

No.	Pipe line	Pressure test for tightness kgf/sq.cm	Remarks
1	<u>Distilled water pipe line</u> (a) from valves 13, 15 to the valve on the distilling plant pipe line (b) from valves 15, 22, 24 to the distilled water stowage tanks	12.5  0.8	Tested under hydraulic pres- sure Tested under air pressure together with tanks
2	<u>Air pipe line</u> (a) from the air pipe line of No.1 fresh water tank to valves 1, 6 to the plug- nut of No. 3 distilled water stowage tank and to the distilled water stowage tanks (b) from valves 1, 6 to the bilge	0.8  In operation	Tested under air pressure together with tanks

#### B. GENERAL DESCRIPTION AND DESCRIPTION OF INDIVIDUAL UNITS

The distilling system (see the accompanying drawing) includes two tanks and pipe lines with fittings.

The distilled water pipe line consists of the main with the branch pipes running as follows:

in No. I compartment - to the distilled water stowage tanks, to the battery well cooling pipe line, to valve 22 and to sampling valve 24;

in Nos II and IV compartments - to the battery wells.

In No. VI compartment the distilled water main is connected with the pipe line of the electric distilling plant.

The distillate is stowed in special distilled water stowage tanks Nos 1 and 2 located in No. I compartment.

The distillate is fed to the tanks either by gravity through funnel 18 or under pressure through hose 16.

Funnel 18 or hose 16 are screwed on the upper part of sleeve 19, feed hose 20 being screwed on the lower portion of the sleeve. The feed hose is fed to the compartment through the torpedo embarkation hatch to valve 22.

SECRET

50X1-HUM

SECRET

50X1-HUM

The tanks when being filled are vented through the vent pipes with vent valves 1 and 6.

Make-up water is fed to the battery wells from the tanks through valves 13 with the help of detachable hoses 14. One detachable hose 14 is provided per battery well.

From the tanks water is expelled with compressed air supplied from the air pipe line of No.1 fresh water tank through valves 7 and 25.

The air is fed to the tanks under a pressure of approximately 0.8 kgf/sq.cm.

To check the pressure in the tanks which should not exceed 0.9 kgf/sq.cm, the ends of the pipes feeding the air to the tanks mount pressure gauges 4, 9 and safety valves 2, 8 set for a pressure of 0.9 kgf/sq.cm.

The air supply pipe line is equipped with a branch pipe with valve 26 to feed the air to No.3 distilled water tank of the battery well cooling system.

Arranged on the water pipe line of the distilling system is a branch pipe running to the battery well cooling pipe line. This branch pipe is used to feed the distillate to the battery well cooling system in the course of loading.

Prior to feeding the distillate for filling the tanks and for make-up of the battery, the distillate shall be sampled and tested in accordance with the Submarine Storage Batteries Upkeep Instructions.

A sample of water is taken through sampling valve 24.

If water does not correspond to the requirements specified in the Submarine Storage Batteries Upkeep Instructions, the tanks shall be drained to the fresh drinking or washing water tanks or to the sanitary tanks. This water may be used for washing purposes.

The remaining make-up water is transferred to the fresh water tank if the distilled water stowage tanks are compensated with sea water.

The distilled water is supplied to the fresh water tanks through feed hose 20 connected to valve 22 and to the respective valve seated on the drinking, washing and sanitary water pipe lines.

The distilled water stowage tanks may be replenished from the electric distilling plant in accordance with the instructions for maintenance of the distilling plant pipe lines.

After the stock of water has been consumed from the tanks, air from them is bled to the compartment through the vent pipes with vent valves 1 and 6, and the tanks may be flooded with sea water, if necessary, which is accomplished from the end valve on the drain main through the hose along the compensating pipes with nuts 3 and 10 (see the instructions for maintenance of the trim and drain systems).

The tanks may be flooded when the submarine is on the surface or when she is snorting, for which purpose proceed in strict adherence to the instructions for consumption of and compensation for variable weights.

Sea water is drained from the tanks with the aid of the bilge pump which removes water through the end valve on the shipboard drain main and through the hose connected to the compensating pipes with nuts 3 and 10 of the shipboard drain main.

SECRET

50X1-HUM

SECRET

50X1-HUM

## C. CONTROL INSTRUMENTS

Table 3

No. acc. to schematic diagram	Description	Type of instrument and scale	Rated value limit value	Installed
4, 9	Pressure gauge to measure pressure of air in Nos 1 and 2 distilled water stowage tanks	MTH-1000 0-1.5 kgf/cm <sup>2</sup> sq.cm. division value 0.1 kgf/cm <sup>2</sup> sq.cm.	0.3	On pipes feeding air to Nos 1 and 2 distilled water stowage tanks

SECRET

50X1-HUM

SECRET

50X1-HUM

## II. MAINTENANCE INSTRUCTIONS

### A. GENERAL SUPERVISION AND UPKEEP

1. In the course of operation of the distilling system, keep the fittings and the pipe lines in good order, take care that they are properly secured to the hull structural members.
2. When operating the distilling system:
  - (a) keep the pipe lines and the fittings in constant readiness for immediate action;
  - (b) ensure that the pipe lines, joints and fittings are perfectly tight; immediately eliminate leaks in union connections and in gland packings;
  - (c) see to it that all the valves and the hoses are always easy to get at;
  - (d) smoothly open the valves on the pipe lines under pressure;
  - (e) tighten up and repack the glands if necessary.
3. Care should be exercised to see that the pressure gauges and the safety valves are in good order and sealed; if the pressure gauges produce wrong readings, their sealing is disturbed or the term of their check is up, they shall be sent for checking or replaced.
4. With the distilling plant in operation, pay attention to condition of the fittings and the pressure gauges, see to it that the pipes are free from cracks and their joints are perfectly tight.
5. In case of disassembly and reassembly of the pipes care should be taken that no foreign matter is allowed to get into them, for which purpose blank off the ends of the disconnected pipes with wooden or metal plugs.  
Never blank off the pipes with rags since they are likely to get into the pipes.
6. In disassembly and reassembly of the pipes use the specified tools not to damage the pipes.
7. Separate sections of the pipes which were disassembled should be tested for tightness in accordance with Table 2.

### B. PREPARATORY STEPS

#### Initial Position

1. Distilled water stowage tanks are filled with distillate.
2. All valves and the cocks are shut.

SECRET

50X1-HUM

SECRET

50X1-HUM

10. All the hoses are disconnected from the valves and are stowed in their proper places.

11. Plug-nuts are placed on valves 13, 22, 24, on sleeve 19 and on the compensating pipes.

#### Preparation for action

12. Bring the system to the initial position.

### C. STARTING, DURING-OPERATION MAINTENANCE AND STOPPING

The procedures outlined under the previous Section are supposed to have been performed.

The valves and cocks to be opened (shut) for the procedures of this Section shall be shut (opened) after fulfilment of a procedure.

#### Feeding the distilled water

Prior to feeding the distilled water, do the following:

13. Remove plug-nuts 17 from sleeve 19 and screw down hose 18 or feed hose 16 on the upper pipe union of the sleeve.
14. Remove plug-nut 21 from valve 22.
15. Connect hose 20 to the lower pipe union of sleeve 22 and valve 22.
16. Remove plug-nut 23 from valve 24.
17. Open vent valves 1 and 6.
18. Open valve 22.
19. Open valve 24 and drain 6-8 litres of water to a portable vessel.
20. Shut valve 24.
21. Open valves 5 and 11.
22. After water starts escaping from the vent valve of the tanks and respective feed valves 5 and 11, next shut vent valves 1 and 6.

#### Feeding make-up water to batteries

Depending on the battery well for which make-up water is to be provided as follows:

23. Remove plug-nut 12 from respective valve 13 and connect it with respective hose 14 with a make-up cock.
24. Open valve 5 or 11 depending on the tank from which water is to be transferred.
25. Open valve 15.
26. Open the respective valves on the pipe line feeding air to No. 1 fresh water tank, proceeding in accordance with the "Drinking, Washing and Sanitary Systems, Description and Maintenance Instructions" and feed air to the air line of the distilling system.
27. Open valve 7 or 25 and observing pressure gauge 3 or 4 create in the respective tank a pressure not exceeding 0.8 kgf/sq.cm, after which shut valves 7 or 25.

SECRET

50X1-HUM



SECRET

50X1-HUM

28. Open respective valve 13.

29. By cracking the cock on hose 14, feed make-up water to the battery.

Note: In case pressure in the air cushion drops when consuming water from the tanks, repeat the procedure outlined under Item 27.

Replenishing the distilled water stowage tanks  
from the electric distilling plant

30. Perform the respective procedures in accordance with the instructions for maintenance of the electric distilling plant pipe lines.

31. Remove plug-nut 23 from valve 24.

32. Open vent valve 1 or 6 depending on the tank to be replenished.

33. Open valve 15.

34. Open valve 24 and drain approximately 12-15 litres of water to a portable vessel.

35. Shut valve 24.

36. Open valve 5 or 11 depending on the tank to be replenished.

37. After water starts escaping from the tank vent valves, shut valve 5 or 11, after which shut vent valve 1 or 6.

Feeding distillate to the fresh water tanks

Prior to feeding the distillate to the fresh water tanks, proceed as follows:

38. Remove plug-nut 21 from valve 22.

39. Connect hose 20 to valve 22 and to the respective valve on the drinking, washing and sanitary water pipe lines.

40. Open valve 22.

41. Perform the procedures outlined under Items 24, 26 and 27.

42. Perform the respective procedures in accordance with the Instructions for maintenance of drinking, washing and sanitary water system.

43. After draining the tanks, bleed the air by opening respective vent valve 1 or 6.

Flooding the tanks with sea water  
and draining them

To flood the distilled water stowage tanks with sea water, do the following:

44. Open respective vent valve 1 or 6 depending on the tank to be replenished and bleed the air from the respective tank.

45. Remove respective plug 25 on the respective compensating pipe and connect the hose to it running from the end valve on the drain main.

46. Flood the respective tank with sea water performing the procedures in accordance with the Instructions for maintenance of the drain and trim systems.

SECRET

50X1-HUM

50X1-HUM

SECRET

47. As soon as water shows from the tank vent pipe, cut off water supply as prescribed by the Instructions for maintenance of the drain and trim systems.

48. Shut respective vent valve 1 or 6.

To drain sea water from the distilled water stowage tanks, it is necessary to do the following.

49. Open respective vent valve 1 or 6 depending on the tank to be drained.

50. Remove respective plug 3 or 10 on the respective compensating pipe and connect the hose to it from the end valve on the drain main.

51. Prepare the drain system proceeding in accordance with the Instructions for maintenance of the drain and trim systems and drain the tanks in turn.

52. After sea water has been drained from the tanks, fill them with fresh water for three times and every time let them stand with fresh water for an hour, after which remove manholes, then fill the tanks with distilled water and take a sample of the distilled water to test for impurities (See the "Submarine Storage Batteries" paragraph 10, 11, 12).

#### D. MAINTENANCE DURING PROTRACTED SHUT-DOWN

53. In case of protracted shut-down of the drain and trim system, do the following:

(a) blow the pipe lines with compressed air;

(b) check the amount of water in the tanks and if necessary, drain the tanks and the joints in the lower part of the drain main and compensating pipes, then tightly screw the caps on the drain main.

54. To set the automatic operation of the drain and trim system, connect the drain main to the drain system and work out all the valves and connections.

55. Check the system.

56. Check the system.

57. Check the system.

58. Check the system.

59. Check the system.

#### E. TROUBLESHOOTING

In case the pipe lines are to be disconnected, make sure that the pipe lines are not under pressure. To do this, close the valve to remove pressure and drain water from the respective section of the pipe line.

The table below gives possible troubles and their remedies.

50X1-HUM

SECRET

SECRET

50X1-HUM

Table 4

No.	Symptom or difficulty	Condition may be due to	Correction
1	Gland packings of valves and cocks leaky	Nuts pressing gland packings loose, gland packings worn	Tighten up nuts of glands, replace gland packing
2	Valves untight	Uneven wear of or damage to fitting surfaces of discs or saddles	Lap valve discs
3	Union joints untight	Nuts loose, gaskets worn	Tighten up nuts, replace gaskets

**Note:** Where disassembly of pipes has been called for trouble correction, test the pipes for tightness in accordance with the directions given in Table 2.

#### F. PREVENTIVE MAINTENANCE AND REPAIRS

These are carried out as follows:

##### Daily Inspection

55. Make sure that seals are present on the safety valves and pressure gauges.

##### Weekly Inspection

Follow the procedures of daily inspection and besides do the follow-

ing: 1. Check the condition of the valves and cocks. 2. Check the condition of the pipes and fittings. 3. Check the condition of the gaskets and seals. 4. Check the condition of the nuts and bolts.

Perform the following:

SECRET

50X1-HUM

SECRET

50X1-HUM

60. Clean the distilled water stowage tanks to remove sediment from them.

#### Inspection during Running Repair

Perform the procedures of three months inspection and test as the following:

61. Disassemble, inspect and adjust the safety valves.
62. If necessary, disassemble, inspect and repair separate valves, replace worn packings and gaskets.
63. Check the painted surfaces of the tanks for corrosion, make touch-up, if necessary.
64. Check the assembled water and air pipe lines and the water stowage tanks for tightness in accordance with Table 1.
65. Once a year send the pressure gauges for calibration.
66. Once a year and after tripping, check the operation of the pressure gauges, pressure switches, low level float switch, and the high level float switch.

#### Annual Inspection and Test

67. Pipe line test at 100 psi.
68. Test at 100 psi, 10 minutes.
69. Remove plug-nut 12 from valve 11.
70. Turn valve 11 to work the pump and check the operation of the rest of valves 1 and 10 and the operation of the electric distilling plant in the system.
71. When the pipe line shall be tested, the pump shall be running the pipe line, shut valve 11.
72. Use a pump to build up a pressure of 100 psi.
73. Check the pipe joints and the fittings for tightness.
74. After testing the pipe line, remove the pump.
75. After testing the pipe line, remove the pump. When the pump is connected, disconnect the pump from the pipe line and connect plug-nut 12 to valve 11.

#### G. REFERENCE DATA

The rubber hoses used in the distilling system are stored in the compartments of the submarine as indicated in the Table below.

SECRET

50X1-HUM

SECRET

50X1-HUM

Table 5


No.	Place to schematic diagram	Dim. and length	Qty	Used	Compartment
1	14	dia. 10, L = 10 m	4	For battery make-up	II and IV
2	16	dia. 25, L = 20 m	1	To receive distilled water	I
3	20	dia. 25, L = 3 m	1	To feed distilled water	I

SECRET

50X1-HUM

SECRET

50X1-HUM




SECRET

50X1-HUM

SECRET

50X1-HUM




SECRET

50X1-HUM

SECRET

50X1-HUM




SECRET

50X1-HUM



SECRET

50X1-HUM




SECRET

50X1-HUM

SECRET

50X1-HUM



SECRET

50X1-HUM

SECRET

50X1-HUM

## CONTENTS

Page

## I. DESCRIPTION

A. Purpose and Basic Specifications .....	3
B. General Description and Description of Individual Units ....	4
C. Control Instruments .....	6

## II. MAINTENANCE INSTRUCTIONS

A. General Supervision and Upkeep .....	7
B. Preparatory Steps .....	7
C. Starting, During-Operation Maintenance and Stopping .....	8
D. Maintenance During Prolonged Standby Period .....	10
E. Troubles and Remedies .....	10
F. Preventive Maintenance .....	11
G. Reference Data .....	12

Appendix: Drilling Instrumentation Diagram

15

SECRET

50X1-HUM

50X1-HUM

**Page Denied**